



Bernad[®]
equipamiento industria alimentaria

BR15 WEIGHT INDICATOR

ABS weight-tare indicator with 30 mm LCD, battery up to 160 h and RS232 output

WEIGHT-TARE

30 MM LCD

160 H BATTERY

RS232



DESCRIPTION

The BR15 is the weight-tare indicator used on ZFZ, ZFN, TMZ or TZ scales: IP54 ABS housing, 30 mm backlit LCD with three backlight modes and sealed 5-key keypad.

Its 6 V/4 Ah battery lasts about 120 hours with backlight and 160 without. It handles up to 4 × 350 Ω or 8 × 700 Ω load cells, has an RS232 output for PC or printer and mounts on a column or wall.

Accumulation, piece counting, limit checking and four hold modes, including moving animal.

CONSTRUCTION AND STANDARD EQUIPMENT

- ABS housing, IP54
- 6-digit 30 mm backlit LCD
- 6 V/4 Ah battery (120-160 h)
- RS232 output; column bracket and wall mounting

KEY DATA

Type	Weight-tare	Housing	ABS IP54	Display	30 mm LCD
Battery	120-160 h	Load cells	up to 4 × 350 Ω	Output	RS232

VERSIONS

REF.	VERSION
260190	ABS weight-tare indicator

Baxtran references. Other configurations on request.

APPLICATIONS

To build or upgrade scales with any compatible weighing platform: food industry, warehouses, logistics and workshops.

For information only. Specifications, dimensions and finishes may change without notice due to product improvements. The image is indicative. Please request a quotation to confirm dimensions, materials and lead times.