

OPTIONAL RS232 OUTPUT FOR SCALES


Optional RS232 output kit for FFN, NFN, BC, BCP, BFS, BW, MKS, MR, SR, TMN and ZW scales

RS232

OPTIONAL

11 MODELS

PRINTER / PC



DESCRIPTION

Baxtran scales without a serial port as standard can be fitted with an optional RS232 output to send the weight to a printer, label printer or computer.

Each scale model has its own kit: FFN, NFN, BC, BCP, BFS, BW, MKS, MR, SR, TMN and ZW.

Order it with the scale to receive it ready; to connect it, see also our RS232 cables.

CONSTRUCTION AND STANDARD EQUIPMENT

- RS232 serial output for the scale
- Specific kit for each model
- Sends weight to printer or PC
- Available for 11 models

KEY DATA

Interface	RS232	Type	Optional	Models	11
Target	Printer/PC	Fitting	In scale	Brand	Baxtran

VERSIONS

REF.	FOR	REF.	FOR
FFN232	FFN scale	MKS232	MKS scale
NFN232	NFN scale	MR232	MR scale
BC232	BC scale	SR232	SR scale
BCP232	BCP scale	TMN232	TMN scale
BFS232	BFS scale	ZW232	ZW scale
BW232	BW scale		

Baxtran references. Other configurations on request.

APPLICATIONS

To complete and install Baxtran scales, balances and indicators in shops, warehouses, industry and laboratories.

For information only. Specifications, dimensions and finishes may change without notice due to product improvements. The image is indicative. Please request a quotation to confirm dimensions, materials and lead times.